

REMOVE SOIL FROM TRUNK FLARE

SCARIFY SIDES OF HOLE

TRIM WIRE BASKET 6" ABOVE BASE



BACKFILL 6" LIFT. ALL BACKFILLING SHALL BE TAMPED FIRMLY BUT NOT TO FULLY COMPACT SOIL.




TRIM AND PEEL AWAY NEXT 6" OF BASKET AND BURLAP




**BACKFILL NEXT 6" LIFT** 

## REPEAT STEPS 3 AND 4 AT DEPTHS OF 6" UNTIL REACHING THE TOP OF THE ROOT BALL



REMOVE REMAINDER OF BASKET



BACKFILL REMAINDER OF SOIL; NO BACKFILL SOIL OR MULCH SHALL BE PLACED ON THE TRUNK FLARE.

## BALL AND BURLAP PREPARATION AND REMOVAL

NTS

CSI 32 92 00 - 5
PLANTING - B&B REMOVAL
LANDSCAPE STANDARDS

PRIOR TO CONSTRUCTION, CONFIRM LAYOUT, DIMENSIONS, ADJACENT UTILITIES AND FINAL MATERIALS WITH U OF P OFICE OF THE UNIVERSITY ARCHITECT. THIS DETAIL TO BE USED AS A GUIDE ONLY. SPECIFIC REVISIONS FOR SITE CONDITIONS AND INTENT ARE THE RESPONSIBILITY OF THE INDIVIDUAL PROJECT DESIGNER.



Facilities & Real Estate Services
Office of the University Architect