

- LOOSEN SUBGRADE OF PLANTING BEDS TO A MIN. DEPTH OF 9", OR TO THE DEPTH OF THE LARGEST CONTAINER PLANT USED.
- 2. REMOVE STONES LARGER THAN 1" IN DIMENSION AND STICKS, ROOTS, RUBBISH, AND OTHER EXTRANEOUS MATTER AND LEGALLY DISPOSE OF THEM OFF OWNER'S PROPERTY.
- 3. THOROUGHLY BLEND PLANTING SOIL MIX OFF-SITE BEFORE SPREADING OR SPREAD TOPSOIL, APPLY SOIL AMENDMENTS AND FERTILIZER ON SURFACE, AND THOROUGHLY BLEND PLANTING SOIL MIX.
- 4. SPREAD PLANTING SOIL MIX TO A DEPTH OF 9"
 BUT NOT LESS THAN REQUIRED TO MEET
 FINISH GRADES AFTER NATURAL SETTLEMENT.
 DO NOT SPREAD IF PLANTING SOIL OR
 SUBGRADE IS FROZEN, MUDDY OR
 EXCESSIVELY WET.
- 5. GRADE PLANTING BEDS TO SMOOTH, UNIFORM SURFACE PLANE WITH LOOSE, UNIFORMLY FINE TEXTURE. ROLL AND RAKE, REMOVE RIDGES, AND FILL DEPRESSIONS TO MEET FINISH GRADES

CSI 32 90 00

BED PREPARATION
LANDSCAPE STANDARDS

PRIOR TO CONSTRUCTION, CONFIRM LAYOUT, DIMENSIONS, ADJACENT UTILITIES AND FINAL MATERIALS WITH U OF P OFFICE OF THE UNIVERSITY ARCHITECT. THIS DETAIL TO BE USED AS A GUIDE ONLY. SPECIFIC REVISIONS FOR SITE CONDITIONS AND INTENT ARE THE RESPONSIBILITY OF THE INDIVIDUAL PROJECT DESIGNER.

